

# CCS Polished Concrete System – High Gloss

Step	Grinding Metal Bond	Polishing Resin Bond	CCS Product	Description
1	40 Grit (F)			<b>Grind – 1 to 3 passes depending on aggregate exposure level required/medium RPM</b> This grind opens the surface up and minimises variations in the surface and depending on aggregate exposure and final appearance desired. <i>Ensure floor is clean before moving to step 2.</i>
2 See Note			<b>CCS Formula CSH-150</b>	<b>Product Application – Only required if concrete is chalky/soft/brittle/weak below 32Mpa</b> Apply CCS Formula CSH-150 (refer to TDS) directly to the floor from watering can and spread out using a broom. Allow product at least 60 minutes to react with the concrete. CSH-150 reacts with the calcium silicate hydrate to block capillaries & close off the concrete.
3	80 Grit (F)			<b>Grind – 1 to 2 passes/medium RPM</b> This grind assists in removing deeper scratches from step 1 grind. <i>Ensure floor is clean before moving to step 4.</i>
4			<b>CCS Formula CSH-90</b>	<b>Product Application</b> Apply CCS Formula CSH-90 (refer to TDS) directly to the floor from watering can and spread out using a broom. <b>Allow product at least 60 minutes to react with concrete, the longer the better.</b> CSH-90 reacts with the calcium silicate hydrate to block capillaries & close off the concrete.
5	120 Grit (F)		<b>CCS GroutSol 90</b>	<b>Grind – 2 passes/medium RPM</b> Apply CCS Groutform (refer to TDS) by spraying a generous volume directly onto the surface 3-5 metres in front of the grinder to ensure the solution remains liquid and does not dry out. Grind surface to produce new concrete dust which will be forced into the pin holes and divots by the grinding process.
6				<b>Surface Inspection</b> Inspect surface by wiping with a cloth then tapping hard with hand to gauge how well the pin holes, divots and crevices have been filled. If micro holes are evident then move onto Step 7. If satisfied with surface move directly onto Step 8.
7		50 Grit (F) Ceramic is preferable	<b>CCS GroutSol 90</b>	<b>Grind – 1 pass/medium RPM (optional step)</b> Inspect surface by wiping with a cloth then tapping hard with hand to gauge how well the pin holes and divots have been filled. If micro holes still exist repeat Step 5 but using 50 Grit Resin.
8		100 Grit (F)		<b>Polish – 2 passes</b> Polish surface using 100 grit resin bond diamonds.
9			<b>CCS Densa-Con</b>	<b>Polish Surface</b> Apply a lick coat of CCS Densa-Con using a microfibre applicator
10		200 Grit (F)		<b>Polish – 2 passes</b> Polish surface using 200 grit resin bond diamonds.

